

INSTRUCTIONS

ANVIL REPLACEMENT 150 & 175 CALIPERS

REPLACEMENT

CAUTION

WEAR ADEQUATE EYE PROTECTION, GLOVES AND CLOTHING DURING INSTALLATION. BRAKE FLUID MAY CAUSE EYE IRRITATION. IN CASE OF EYE CONTACT, FLUSH WITH WATER FOR 20 MINUTES AND GET IMMEDIATE MEDICAL ATTENTION.

1. Disconnect brake line from caliper and remove caliper from vehicle.

CAUTION – Be careful not to contaminate brake linings with brake fluid.

2. Remove two caliper assembly nuts & bolts and remove anvil from caliper.
3. Remove bolt from anvil lining and remove lining.
4. Install lining in new anvil and attach with the original screw. (torque to 15 - 20 in. lbs.)
5. Reassemble anvil with lining to caliper using original bolts. Torque bolts to:
 - 22 ft. lbs. on 150 calipers
 - 35 ft. lbs. on 175 calipers
6. Install caliper on vehicle; reattach hydraulic brake line, and bleed system.
7. Prior to use, test caliper to verify function.

AIRHEART® BRAKE CO., Hamel, MN 55430, USA
3999-0043_00 www.tolomatic.com